TripleSafe™ SUMP PUMP SYSTEM

SCENARIOS

If Pump 1 fails: Pump 2 takes over!

If Pump 1 can't keep up: <u>Both</u> pumps 1 and 2 operate a total of 6,200 gallons per hour!

If Power fails: Pump 3, a battery operated "UltraSump", takes over!



Pump 3-UltraSump[®] Battery Back-up Pumping System

Pump 3 is a DC operated pump – which means if your power or circuit breakers fail, this pump operates off battery power to get the water out – completing your protection. (Battery and automatic charging system are included)

> Pump 1-Zoeller M-53 1/3 hp Pump

Pump 1 does the pumping most of the time. It is a reliable, efficient, smooth running 1/3 hp cast iron pump. The on and off switching on all 3 pumps is automatic.

Triple the Protection!

The World's Most Reliable Pumping System!



Pump 2-Zoeller M-98 1/2 hp High Volume Pump Pump 2 operates when either pump 1 fails, or if pump 1 can not keep up with a heavy flow of water

ON

in a hard fast rain – then pumps 1 & 2 operate at the same time. Because they are on separate discharge pipes, they will remove up to 6200 gallons per hour out of your basement! And, pump 2 is bigger, giving you that "turbo boost" when you need it.


Pump 3 operating range

Pump 2 operating range

Pump 1 operating range









TripleSafe[™] is protected by multiple patents and patents pending

*Two electrical outlets on separate circuits not included.

TripleSafe™ SUMP PUMP SYSTEM







The unique TripleSafe[™] Cross "Bridge", provides strength & support to the lids, cable management and pipe location cradles. The entire system is engineered to perfection, taking every detail into consideration.





A SaniDry[™] Basement Air System will dry the air in your basement or crawl space and automatically drain the water into the TripleSafe[™], so you never have to empty it. The SaniDry[™] System is a great addition keeping humidity down, so odors go away and mold will not grow.



TripleSafe[™] shown with Basement Systems' award winning engineered WaterGuard[®] Basement Drainage System, and BrightWall[™] Paneling System.

*Not included in the TripleSafe[™] installation by your Basement Systems dealer are two electrical outlets on two separate circuits, which must be provided by the homeowner. See Warranty provided by local dealer for warranty information. No warranty is implied by this brochure.